

Need Power? Grab a Charger !

Step One: Pick a charger

Select any available Omnicharge charger from the Power Station.

Step Two: Charge up

Charge your laptop, tablet, phone, or practically any other devices.

Step Three: Return when done

When you're finished, simply plug the charger back into any available slot.



Button Fuctions

PRIMARY CONTROLS

– Quick press to power On
– Long press to power Off

– Up Button: DC Outlet
– Down Button: Wireless & USB

MENU CONTROLS

– Double press to enter the menu
– Quick press to select

– Up Button: Move Up
– Down Button: Move Down

Up to 30 charges Earbuds	**Up to 45 charges** Smartwatches	**Up to 4 charges** Smartphones	**Up to 2 charges** Tablets	**Up to 2 charges** 13" Laptops	**Up to 10 charges** DSLR Cameras

For more information, please visit www.omnicharge.co